



GENIUS X2

Pre Wash

- Genius X² is activated shortly after the cycle starts, removing food soil from the wash water, prior to washing

Wash

- Prior to rinsing the Genius X² is activated removing any remaining food soil
- Interlocked strainer ensures correct location and operation of filter system

The double activation of the Genius X² filter systems ensures maximum removal of food soil, reducing chemical cost and improving wash results.

