

A dishwasher should be easy to use and customers tell us that having simple, understandable controls is of key importance - FX and FXP deliver on both counts by offering:

- Single button activation for filling, cycle start and draining
- Colour coded sequence gives clear indication of machine status
- Additional functions eg. cycle selection and temperature indication can be accessed as required
- Less risk of incorrect operation and misuse



*GREEN - READY/STANDBY*



*BLUE - WASHING*



*CYCLE STATUS INDICATOR*