BRU Filter Papers -

Case of 1000 8000200

ASSOCIATED PRODUCTS (SOLD SEPARATELY)

BRU F45M/F45A 1000900/1000901	BRU F60M/F60A 1000902/1000903	DIMENSIONS
Contract of the Contract of th	Morra O	H

- 1.8 jug or 2.2 litre flask options
- Manual and automatic fill options

- Improved sprayhead performance
- Simple set up, service and refurb

2.2l Airpot

1700179

ENERGY-EFFICIENT AND EASY TO USE SMALL BATCH BREWERS FOR CANTEENS, COFFEE SHOPS, BUSINESSES OR CONFERENCES.

AIRPOT 2.2L (FOR BRU F60M/F60A) 1700179

NAME ORDER CODE	PACKED WEIGHT	PACKAGING DIMENSIONS (L x W x H mm)	QTY/PALLET
F45M Jug Manual Fill 1000900	01	600 x 250 x 507	24
F45A Jug Auto Fill 1000901	8kg		
F60M Flask Manual Fill 1000902	Oka	420 v 250 v 657	20
	9kg	420 x 250 x 657	20

NAME ORDER CODE	POWER @ 230V	BREW CAPACITY	DIMENSIONS (D x W x H mm)	PLUMBING REQS
F45M Jug Manual Fill 1000900	- 2.4kW	1.8L	365 x 214 x 446	_
F45A Jug Auto Fill 1000901				3/4" BSP
F60M Flask Manual Fill 1000902	2.2kW	2.2L	365 x 214 x 598	_
F60A Flask Auto Fill 1000903				3/4" BSP

F60A Flask Auto Fill

1000903

BRU marco

BRU							
BRU F45M	BRU F45A	BRU F60M	BRU F60A				
1000900	1000901	1000902	1000903				

PLUMBING INSTALLATION PROCEDURE

- Fit a stop valve and suitable fitting on a cold water line (e.g. 3/4" x 1/2" 311 or washing machine type stop valve).
- The boiler requires a suitable food grade inlet hose with 3/4".
- BSP female elbow fitting which will attach to the underside of the machine.
- Make sure that the pre-attached sealing washer is fitted on both ends.
- Turn on the water to flush any impurities, dust etc. from the inlet hose and water pipe. Allow several gallons through.

- Connect right-angled tailpiece of the hose to the inlet valve of the boiler (again 3/4" BSP). Make sure the sealing washer is fitted here again.
- Turn on water and check for leaks.

NOTE: Using a non-food grade hose (e.g. a washing machine hose) will usually result in off-tastes & smells in the water, and can possibly be toxic.