
















Machine	Explode	Code	Description
Buffalo Pasta Maker	1	AF049	Fuse
Buffalo Pasta Maker	2	AE837	Timer
Buffalo Pasta Maker	3	AF055	Knob
Buffalo Pasta Maker	4	AF051	Thermostat
Buffalo Pasta Maker	5		Electrical Box
Buffalo Pasta Maker	6		Hook
Buffalo Pasta Maker	7		Clip
Buffalo Pasta Maker	8	AF378	Basket
Buffalo Pasta Maker	9		Hook Assembly
Buffalo Pasta Maker	10	AF040	Corrugated Pipe
Buffalo Pasta Maker	11	N303	Flange
Buffalo Pasta Maker	12		Seal
Buffalo Pasta Maker	13	N302	Drain Tap
Buffalo Pasta Maker	14	AC282	¾" – ½" Nut
Buffalo Pasta Maker	15		Plug & Lead
Buffalo Pasta Maker	16		Back Cover
Buffalo Pasta Maker	17	AF048	Switch
Buffalo Pasta Maker	18		Box Assembly
Buffalo Pasta Maker	19		Hardware Assembly
Buffalo Pasta Maker	19-1		Hardware Assembly
Buffalo Pasta Maker	20		Nut
Buffalo Pasta Maker	21		Element Cover
Buffalo Pasta Maker	22	AF053	Element
Buffalo Pasta Maker	23		Lid Assembly
Buffalo Pasta Maker	24		Drip Tray Assembly
Buffalo Pasta Maker	25		Body
Buffalo Pasta Maker	26	AA014	Feet