
















Machine	Explode	Code	Description
GJ452 - Buffalo Jumbo Panini Grill	1	AG199	Handle Assembly
GJ452 - Buffalo Jumbo Panini Grill	2		Top Cover
GJ452 - Buffalo Jumbo Panini Grill	3		Insulation Clamp (Upper)
GJ452 - Buffalo Jumbo Panini Grill	4		Element Fixing Plate (Upper)
GJ452 - Buffalo Jumbo Panini Grill	5	AF412	Upper Heating Element
GJ452 - Buffalo Jumbo Panini Grill	6		Pipe
GJ452 - Buffalo Jumbo Panini Grill	7		Hardware Assembly (Upper)
GJ452 - Buffalo Jumbo Panini Grill	8		Cast Plate (Upper)
GJ452 - Buffalo Jumbo Panini Grill	9		Treaded Rods
GJ452 - Buffalo Jumbo Panini Grill	10	AG599	Reset Cap
GJ452 - Buffalo Jumbo Panini Grill	11	AG598	Reset Plate
GJ452 - Buffalo Jumbo Panini Grill	12	AG597	Reset Stick
GJ452 - Buffalo Jumbo Panini Grill	13	N126	Thermal Cut Out
GJ452 - Buffalo Jumbo Panini Grill	14		Cast Plate (Lower)
GJ452 - Buffalo Jumbo Panini Grill	15		Body
GJ452 - Buffalo Jumbo Panini Grill	16		Handle
GJ452 - Buffalo Jumbo Panini Grill	17	AF408	Lower Heating Element
GJ452 - Buffalo Jumbo Panini Grill	18		Element Fixing Plate (Lower)
GJ452 - Buffalo Jumbo Panini Grill	19		Insulation Clamp (Lower)
GJ452 - Buffalo Jumbo Panini Grill	20		Hardware Assembly (Lower)
GJ452 - Buffalo Jumbo Panini Grill	21	N152	Foot
GJ452 - Buffalo Jumbo Panini Grill	22		Base Plate
GJ452 - Buffalo Jumbo Panini Grill	23		Oil Tank
GJ452 - Buffalo Jumbo Panini Grill	24	AE837	Timer
GJ452 - Buffalo Jumbo Panini Grill	25	AA031	Indicator Light (Red)
GJ452 - Buffalo Jumbo Panini Grill	26	N129	Dial
GJ452 - Buffalo Jumbo Panini Grill	27	AF409	Switch
GJ452 - Buffalo Jumbo Panini Grill	28	N125	Thermostat