1 | Page

Machine	Explode	Code	Description
K711 Buffalo Electric Airpot - 4.25Ltr 230V	1		Lid
K711 Buffalo Electric Airpot - 4.25Ltr 230V	2		Middle Cover Lock Sticker
K711 Buffalo Electric Airpot - 4.25Ltr 230V	3		Switch
K711 Buffalo Electric Airpot - 4.25Ltr 230V	4		Middle Cover Lock
K711 Buffalo Electric Airpot - 4.25Ltr 230V	5		Middle Cover
K711 Buffalo Electric Airpot - 4.25Ltr 230V	6		Piston Rod
K711 Buffalo Electric Airpot - 4.25Ltr 230V	7		Pressure sealing washer
K711 Buffalo Electric Airpot - 4.25Ltr 230V	8		Guide bar spring
K711 Buffalo Electric Airpot - 4.25Ltr 230V	9		Latch spring
K711 Buffalo Electric Airpot - 4.25Ltr 230V	10		Lid Lock
K711 Buffalo Electric Airpot - 4.25Ltr 230V	11	AA010	Piston rod
K711 Buffalo Electric Airpot - 4.25Ltr 230V	12		Swivel pin
K711 Buffalo Electric Airpot - 4.25Ltr 230V	13		Lid Base
K711 Buffalo Electric Airpot - 4.25Ltr 230V	14		Screw
K711 Buffalo Electric Airpot - 4.25Ltr 230V	15		Sealing Washer
K711 Buffalo Electric Airpot - 4.25Ltr 230V	16		Sealing Cover
K711 Buffalo Electric Airpot - 4.25Ltr 230V	17		Steam outlet
K711 Buffalo Electric Airpot - 4.25Ltr 230V	18		Steam Funnel
K711 Buffalo Electric Airpot - 4.25Ltr 230V	19		Washer
K711 Buffalo Electric Airpot - 4.25Ltr 230V	20		Lid Sealing Washer
K711 Buffalo Electric Airpot - 4.25Ltr 230V	21	1	Metal Deflector Plate
K711 Buffalo Electric Airpot - 4.25Ltr 230V	22		Screw
K711 Buffalo Electric Airpot - 4.25Ltr 230V	23	2	Control Panel Component
K711 Buffalo Electric Airpot - 4.25Ltr 230V	24	2	Light Fixture
K711 Buffalo Electric Airpot - 4.25Ltr 230V	25	2	Wiring
K711 Buffalo Electric Airpot - 4.25Ltr 230V	26	2	Light Fixture Bracket
K711 Buffalo Electric Airpot - 4.25Ltr 230V	27	<u>*************************************</u>	Screw
K711 Buffalo Electric Airpot - 4.25Ltr 230V	28	2	L type outlet water pipe
K711 Buffalo Electric Airpot - 4.25Ltr 230V	29	<u>*************************************</u>	Lip
K711 Buffalo Electric Airpot - 4.25Ltr 230V	30	<u>*************************************</u>	Glass pipe
K711 Buffalo Electric Airpot - 4.25Ltr 230V	31	<u>*************************************</u>	Cup Lever
K711 Buffalo Electric Airpot - 4.25Ltr 230V	32	<u>*************************************</u>	Electric pump inlet water pipe
K711 Buffalo Electric Airpot - 4.25Ltr 230V	33	<u>*************************************</u>	Electric pump outlet water pipe
K711 Buffalo Electric Airpot - 4.25Ltr 230V	34	<u> </u>	Electric pump
K711 Buffalo Electric Airpot - 4.25Ltr 230V	35	<u> </u>	Inner container
K711 Buffalo Electric Airpot - 4.25Ltr 230V	36	<u>~</u>	Fuse
K711 Buffalo Electric Airpot - 4.25Ltr 230V	37	<u>~</u>	Fuse holder
K711 Buffalo Electric Airpot - 4.25Ltr 230V	38	<u> </u>	105° heat regulator
K711 Buffalo Electric Airpot - 4.25Ltr 230V	39	~	Screw
K711 Buffalo Electric Airpot - 4.25Ltr 230V	40	~	Wiring
K711 Buffalo Electric Airpot - 4.25Ltr 230V	41	2	Washer
K711 Buffalo Electric Airpot - 4.25Ltr 230V	42	2	Control Panel Casing
K711 Buffalo Electric Airpot - 4.25Ltr 230V	43	2	Handle
K711 Buffalo Electric Airpot - 4.25Ltr 230V	44	2	Water Pipe Protector
K711 Buffalo Electric Airpot - 4.25Ltr 230V	45	2	Heater Hipe Protector
N/11 DUITAIO EIECUTE AITPUL - 4.23LU 23UV	45		TICALCI

Exploded diagram and spare parts list

1/7	1	1	
к /		- 1	

46	*	Screw	
47	Æ	Fixed Platform	
48	A	Spider	
49	*	Screw	
50	Æ	Wiring Spider	
51	A	Nut	
52	**	Screw	
53	Æ	Washer	
54	Æ	Screw	
55	Æ	Screw	
56	*	Transformer	
57	Æ	92° Heat Regulator	
58	A	Screw	
59	Æ	Heat Regulator Bracket	
60	Æ	Screw	
61	**	Screw	
62	*	Ceramic Isolator	
63	*	Main Circuit Board	
64	A	Screw	
65	*	Water Level Indicator	
67	**	Body	
68	A	Screw	
69	*	Socket	
70	Æ	Base	
71	Æ	Ring	
72	Æ	Bottom Cover	
73	Æ	Screw	
74	~	Screw	
	47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 67 68 69 70 71 72 73	47	