


Exploded diagram and spare parts list L501, L503 & L511


For machines with digital timer:














[Click here](#)


For machines without digital timer:

[Click here](#)















 Technical & Spares helpline 0845 111 0538
spares@uropa-service.co.uk



Machine	Explode	Code	Description
Single Contact Grills: L501 L503 & L511 with Timer	1		Top Cover
Single Contact Grills: L501 L503 & L511 with Timer	2	N481	Main Handle
Single Contact Grills: L501 L503 & L511 with Timer	3		Upper Mica Plate
Single Contact Grills: L501 L503 & L511 with Timer	4		Rear Cover
Single Contact Grills: L501 L503 & L511 with Timer	5	N145	Heating Element Upper
Single Contact Grills: L501 L503 & L511 with Timer	6		Cast Plate Upper
Single Contact Grills: L501 L503 & L511 with Timer	7		Cast Plate Lower
Single Contact Grills: L501 L503 & L511 with Timer	8		Hinge
Single Contact Grills: L501 L503 & L511 with Timer	9	N480	Plate Connecting Spring
Single Contact Grills: L501 L503 & L511 with Timer	10	N153	Heating Element Lower
Single Contact Grills: L501 L503 & L511 with Timer	11		Insulation Plate Lower
Single Contact Grills: L501 L503 & L511 with Timer	12	N126	Thermal Cut Out
Single Contact Grills: L501 L503 & L511 with Timer	13		Main Body
Single Contact Grills: L501 L503 & L511 with Timer	14		Plug & Lead
Single Contact Grills: L501 L503 & L511 with Timer	15		Ceramic Tube
Single Contact Grills: L501 L503 & L511 with Timer	16		Base Plate
Single Contact Grills: L501 L503 & L511 with Timer	17	AC689	Feet
Single Contact Grills: L501 L503 & L511 with Timer	18	N125	Thermostat
Single Contact Grills: L501 L503 & L511 with Timer	19	N129	Dial
Single Contact Grills: L501 L503 & L511 with Timer	20	N486	Indicator Light
Single Contact Grills: L501 L503 & L511 with Timer	21	N146	Switch
Single Contact Grills: L501 L503 & L511 with Timer	22	N477	Drip Tray
Single Contact Grills: L501 L503 & L511 with Timer	23		Lower Mica Plate
Single Contact Grills: L501 L503 & L511 with Timer	24	N484	Small Handle
Single Contact Grills: L501 L503 & L511 with Timer	25		Insulation Plate Upper
Single Contact Grills: L501 L503 & L511 with Timer	26	AD566	Tension Bracket
Single Contact Grills: L501 L503 & L511 with Timer	27	AE837	Timer with Transformer
Single Contact Grills: L501 L503 & L511 with Timer	Not shown	AC638	Wiring Loom



Exploded diagram and spare parts list L501, L503 & L511

Machine	Explode	Code	Description
Single Contact Grills: L501 L503 & L511	1		Top Cover
Single Contact Grills: L501 L503 & L511	2	N481	Main Handle
Single Contact Grills: L501 L503 & L511	3		Upper Mica Plate
Single Contact Grills: L501 L503 & L511	4		Rear Cover
Single Contact Grills: L501 L503 & L511	5	N145	Heating Element Upper
Single Contact Grills: L501 L503 & L511	6		Cast Plate Upper
Single Contact Grills: L501 L503 & L511	7		Cast Plate Lower
Single Contact Grills: L501 L503 & L511	8		Hinge
Single Contact Grills: L501 L503 & L511	9	N480	Plate Connecting Spring
Single Contact Grills: L501 L503 & L511	10	N153	Heating Element Lower
Single Contact Grills: L501 L503 & L511	11		Insulation Plate Lower
Single Contact Grills: L501 L503 & L511	12	N126	Thermal Cut Out
Single Contact Grills: L501 L503 & L511	13		Main Body
Single Contact Grills: L501 L503 & L511	14		Plug & Lead
Single Contact Grills: L501 L503 & L511	15		Ceramic Tube
Single Contact Grills: L501 L503 & L511	16		Base Plate
Single Contact Grills: L501 L503 & L511	17		Feet
Single Contact Grills: L501 L503 & L511	18	N125	Thermostat
Single Contact Grills: L501 L503 & L511	19	N129	Dial
Single Contact Grills: L501 L503 & L511	20	N486	Indicator Light
Single Contact Grills: L501 L503 & L511	21	N146	Switch
Single Contact Grills: L501 L503 & L511	22	N477	Drip Tray
Single Contact Grills: L501 L503 & L511	23		Lower Mica Plate
Single Contact Grills: L501 L503 & L511	24	N484	Small Handle
Single Contact Grills: L501 L503 & L511	25		Insulation Clamp