
For Machines with a Digital Timer



For Machines without a Digital Timer




For Machines with a Digital Timer



Machine	Explode	Code	Description
L518 - Contact Grill Large Ribbed/Ribbed with Timer	1	2	Top Cover
L518 - Contact Grill Large Ribbed/Ribbed with Timer	2	N482	Main Handle
L518 - Contact Grill Large Ribbed/Ribbed with Timer	3	~	Mica Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed with Timer	4	2	Rear Cover
L518 - Contact Grill Large Ribbed/Ribbed with Timer	5	N154	Heating Element Upper
L518 - Contact Grill Large Ribbed/Ribbed with Timer	6	2	Cast Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed with Timer	7	2	Cast Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed with Timer	8	2	Hinge
L518 - Contact Grill Large Ribbed/Ribbed with Timer	9	2	Plate Connecting Spring
L518 - Contact Grill Large Ribbed/Ribbed with Timer	10	N155	Heating Element Lower
L518 - Contact Grill Large Ribbed/Ribbed with Timer	11	2	Insulation Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed with Timer	12	N126	Thermal Cut Out
L518 - Contact Grill Large Ribbed/Ribbed with Timer	13	~	Main Body
L518 - Contact Grill Large Ribbed/Ribbed with Timer	14	~	Plug & Lead
L518 - Contact Grill Large Ribbed/Ribbed with Timer	15	*	Ceramic Tube
L518 - Contact Grill Large Ribbed/Ribbed with Timer	16	*	Base Plate
L518 - Contact Grill Large Ribbed/Ribbed with Timer	17	AC689	Feet
L518 - Contact Grill Large Ribbed/Ribbed with Timer	18	N125	Thermostat
L518 - Contact Grill Large Ribbed/Ribbed with Timer	19	N129	Dial
L518 - Contact Grill Large Ribbed/Ribbed with Timer	20	N486	Indicator Light
L518 - Contact Grill Large Ribbed/Ribbed with Timer	21	N146	Switch
L518 - Contact Grill Large Ribbed/Ribbed with Timer	22	N478	Drip Tray
L518 - Contact Grill Large Ribbed/Ribbed with Timer	23	2	Mica Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed with Timer	24	N484	Small Handle
L518 - Contact Grill Large Ribbed/Ribbed with Timer	25	2	Insulation Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed with Timer	26	AD566	Tension Bracket
L518 - Contact Grill Large Ribbed/Ribbed with Timer	27	AE837	Timer with Transformer
L518 - Contact Grill Large Ribbed/Ribbed with Timer	Not shown	AD565	Wiring Loom
L518 - Contact Grill Large Ribbed/Ribbed with Timer	Not shown	AF494	Decal Sticker

For machines without digital timer:



Machine	Explode	Code	Description
L518 - Contact Grill Large Ribbed/Ribbed	1	~	Top Cover
L518 - Contact Grill Large Ribbed/Ribbed	2	N482	Main Handle
L518 - Contact Grill Large Ribbed/Ribbed	3	~	Mica Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed	4	~	Rear Spring
L518 - Contact Grill Large Ribbed/Ribbed	5	N154	Heating Element Upper
L518 - Contact Grill Large Ribbed/Ribbed	6	*	Cast Plate Upper
L518 - Contact Grill Large Ribbed/Ribbed	7	2	Cast Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed	8	2	Hinge
L518 - Contact Grill Large Ribbed/Ribbed	9	N480	Plate Connecting Spring
L518 - Contact Grill Large Ribbed/Ribbed	10	N155	Heating Element Lower
L518 - Contact Grill Large Ribbed/Ribbed	11	2	Insulation Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed	12	N126	Thermal Cut Out
L518 - Contact Grill Large Ribbed/Ribbed	13	~	Main Body
L518 - Contact Grill Large Ribbed/Ribbed	14	N150	Plug & Lead
L518 - Contact Grill Large Ribbed/Ribbed	15	2	Ceramic Tube
L518 - Contact Grill Large Ribbed/Ribbed	16	~	Base Plate
L518 - Contact Grill Large Ribbed/Ribbed	17	2	Feet
L518 - Contact Grill Large Ribbed/Ribbed	18	N125	Thermostat
L518 - Contact Grill Large Ribbed/Ribbed	19	N129	Dial
L518 - Contact Grill Large Ribbed/Ribbed	20	N486	Indicator Light
L518 - Contact Grill Large Ribbed/Ribbed	21	N146	Switch
L518 - Contact Grill Large Ribbed/Ribbed	22	N478	Drip Tray
L518 - Contact Grill Large Ribbed/Ribbed	23	~	Mica Plate Lower
L518 - Contact Grill Large Ribbed/Ribbed	24	N484	Small Handle
L518 - Contact Grill Large Ribbed/Ribbed	25	2	Insulation Plate Upper