





Machine	Explode	Code	Description
P107 - Buffalo Double Fryer - 2x3Ltr	1	AC841	Cover
P107 - Buffalo Double Fryer - 2x3Ltr	2	N117	Thermal Cut-Out
P107 - Buffalo Double Fryer - 2x3Ltr	3	N124	Dial
P107 - Buffalo Double Fryer - 2x3Ltr	4		Indicator Light
P107 - Buffalo Double Fryer - 2x3Ltr	5	N116	Thermostat
P107 - Buffalo Double Fryer - 2x3Ltr	6		Back Plate
P107 - Buffalo Double Fryer - 2x3Ltr	7		Control Box
P107 - Buffalo Double Fryer - 2x3Ltr	8	N118	Safety Switch
P107 - Buffalo Double Fryer - 2x3Ltr	9	N282	Basket
P107 - Buffalo Double Fryer - 2x3Ltr	10	N280	Element
P107 - Buffalo Double Fryer - 2x3Ltr	11	N279	Oil Pan
P107 - Buffalo Double Fryer - 2x3Ltr	12		Body
P107 - Buffalo Double Fryer - 2x3Ltr	13	N287	Feet