



Machine	Explode	Code	Description
Waring Food Processor	1	AC660	SMALL PUSHER
Waring Food Processor	2	AC661	LARGE PUSHER
Waring Food Processor	3	AC994	BOWL COVER / WFP 7K13
Waring Food Processor	4	AC997	BOWL / WFP7K12
Waring Food Processor	5	AD364	S BLADE / WFP7K1
Waring Food Processor	6	AC996	DISC STEM / BLACK



032288


2mm - 5/64" Slicing Disc



032280

2mm - 5/64" Grating Disc


Machine	Explode	Code	Description
Waring Food Processor Blades		AD366	WARING 2MM SLICING DISC
Waring Food Processor Blades		AD787	WARING 3 MM SLICING DISC
Waring Food Processor Blades		AC986	WARING 4 MM – 5/32" SLICING DISC
Waring Food Processor Blades		AD788	WARING 6 MM SLICING DISC
Waring Food Processor Blades		AC975	5/64" SHREDDING DISC
Waring Food Processor Blades		AC985	WARING 4MM – 5/32" SHREDDING DISC
Waring Food Processor Blades		AC987	WARING 2MM – 5/64" GRATING DISC
Waring Food Processor Blades		AD790	3X3 JULIENNE DISC
Waring Food Processor Blades		AD791	6X6 FRENCH FRY DISC



029441
Start Capacitor




029439
PCB Assy.




029440
Stop Capacitor



029442
Starting Relay



029443
Switch



032287
Bottom Housing
(black)

Machine	Explode	Code	Description
Waring Food Processor	029441	☎	START CAPACITOR
Waring Food Processor	029442	☎	STARTING RELAY
Waring Food Processor	029439	☎	PCB ASSY
Waring Food Processor	029440	☎	STOP CAPACITOR
Waring Food Processor	029443	☎	SWITCH
Waring Food Processor	032287	☎	BOTTOM HOUSING (BLACK)