

Exploded diagram and spare parts list

CD083


For machines with refrigerant R600a

[Click](#)

For machines with refrigerant R134a


[Click](#)

Exploded diagram and spare parts list  
R600a



Machine	Explode	Code	Description
CD083 Polar Freezer St/St - 365Ltr (UK)	1	AD037	Up Hinge
CD083 Polar Freezer St/St - 365Ltr (UK)	2	AD027	Lock Hook
CD083 Polar Freezer St/St - 365Ltr (UK)	4	AG191	Front Panel
CD083 Polar Freezer St/St - 365Ltr (UK)	5	AD026	Hinge Axis
CD083 Polar Freezer St/St - 365Ltr (UK)	6	AB354	Bushing
CD083 Polar Freezer St/St - 365Ltr (UK)	7	AD028	Lock
CD083 Polar Freezer St/St - 365Ltr (UK)	9	AD024	Gasket
CD083 Polar Freezer St/St - 365Ltr (UK)	10		Door
CD083 Polar Freezer St/St - 365Ltr (UK)	11	AD013	Down Hinge
CD083 Polar Freezer St/St - 365Ltr (UK)	12	AD019	Evaporator Support
CD083 Polar Freezer St/St - 365Ltr (UK)	13		Evaporator
CD083 Polar Freezer St/St - 365Ltr (UK)	14	AF885	Feet (Set Of 4)
CD083 Polar Freezer St/St - 365Ltr (UK)	15		Body
CD083 Polar Freezer St/St - 365Ltr (UK)	16		Plug
CD083 Polar Freezer St/St - 365Ltr (UK)	17	AA691	Junction Box
CD083 Polar Freezer St/St - 365Ltr (UK)	18	AG014	Compressor (R600a)
CD083 Polar Freezer St/St - 365Ltr (UK)	19	AD034	Unite Board
CD083 Polar Freezer St/St - 365Ltr (UK)	20	AD201	Condenser
CD083 Polar Freezer St/St - 365Ltr (UK)	21		Condenser Fan Support
CD083 Polar Freezer St/St - 365Ltr (UK)	22	AB339	Condenser Fan
CD083 Polar Freezer St/St - 365Ltr (UK)	23		Unite Room Grills
CD083 Polar Freezer St/St - 365Ltr (UK)	24	AD015	Evaporator Fixer
CD083 Polar Freezer St/St - 365Ltr (UK)	25	AC614	Sensor
CD083 Polar Freezer St/St - 365Ltr (UK)	26	AB363	Thermostat

Exploded diagram and spare parts list  
R134a



Machine	Explode	Code	Description
CD083 Polar Freezer St/St - 365Ltr (UK)	1	AD037	Up Hinge
CD083 Polar Freezer St/St - 365Ltr (UK)	2	AD027	Hook Of Lock
CD083 Polar Freezer St/St - 365Ltr (UK)	3		Thermostat Support
CD083 Polar Freezer St/St - 365Ltr (UK)	4	AD340	Front Panel
CD083 Polar Freezer St/St - 365Ltr (UK)	5	AD026	Hinge Axis
CD083 Polar Freezer St/St - 365Ltr (UK)	6	AB354	Bushing
CD083 Polar Freezer St/St - 365Ltr (UK)	7	AD028	Lock
CD083 Polar Freezer St/St - 365Ltr (UK)	9	AD024	Gasket
CD083 Polar Freezer St/St - 365Ltr (UK)	10		Door
CD083 Polar Freezer St/St - 365Ltr (UK)	11	AD013	Down Hinge
CD083 Polar Freezer St/St - 365Ltr (UK)	12	AD020	Evaporator Support
CD083 Polar Freezer St/St - 365Ltr (UK)	13		Evaporator
CD083 Polar Freezer St/St - 365Ltr (UK)	14	AB361	Foot
CD083 Polar Freezer St/St - 365Ltr (UK)	15		Body
CD083 Polar Freezer St/St - 365Ltr (UK)	16		Plug
CD083 Polar Freezer St/St - 365Ltr (UK)	17	AA691	Junction Box
CD083 Polar Freezer St/St - 365Ltr (UK)	18	AB111	Compressor
CD083 Polar Freezer St/St - 365Ltr (UK)	19	AD034	Unit Board
CD083 Polar Freezer St/St - 365Ltr (UK)	20	AD201	Condenser
CD083 Polar Freezer St/St - 365Ltr (UK)	21		Condenser Fan Support
CD083 Polar Freezer St/St - 365Ltr (UK)	22	AB339	Condenser Fan
CD083 Polar Freezer St/St - 365Ltr (UK)	23		Unit Room Grills
CD083 Polar Freezer St/St - 365Ltr (UK)	24	AD015	Evaporator Fixer
CD083 Polar Freezer St/St - 365Ltr (UK)	25	AC614	Sensor
CD083 Polar Freezer St/St - 365Ltr (UK)	26	AD032	Thermostat