

Exploded diagram and spare parts list

CD085


For machines with refrigerant R600a



[Click](#)

For machines with refrigerant R134a


[Click](#)








Exploded diagram and spare parts list
R600a



Machine	Explode	Code	Description
CD085 Polar Freezer St/St - 600Ltr (UK)	1	AD037	Up Hinge
CD085 Polar Freezer St/St - 600Ltr (UK)	2	AD027	Lock Hook
CD085 Polar Freezer St/St - 600Ltr (UK)	4	AG193	Front Panel
CD085 Polar Freezer St/St - 600Ltr (UK)	5	AD028	Lock
CD085 Polar Freezer St/St - 600Ltr (UK)	6	AB363	Thermostat
CD085 Polar Freezer St/St - 600Ltr (UK)	7	AD026	Hinge Axis
CD085 Polar Freezer St/St - 600Ltr (UK)	8	AB354	Bushing
CD085 Polar Freezer St/St - 600Ltr (UK)	9	AD025	Gasket
CD085 Polar Freezer St/St - 600Ltr (UK)	10		Door
CD085 Polar Freezer St/St - 600Ltr (UK)	12	AD013	Down Hinge
CD085 Polar Freezer St/St - 600Ltr (UK)	13		Evaporator Support
CD085 Polar Freezer St/St - 600Ltr (UK)	14		Evaporator
CD085 Polar Freezer St/St - 600Ltr (UK)	15	AF885	Feet
CD085 Polar Freezer St/St - 600Ltr (UK)	16		Body
CD085 Polar Freezer St/St - 600Ltr (UK)	17		Plug
CD085 Polar Freezer St/St - 600Ltr (UK)	18	AA691	Junction Box
CD085 Polar Freezer St/St - 600Ltr (UK)	19	AG015	Compressor (R600a)
CD085 Polar Freezer St/St - 600Ltr (UK)	20	AB339	Condenser Fan
CD085 Polar Freezer St/St - 600Ltr (UK)	21	AD036	Unite Board
CD085 Polar Freezer St/St - 600Ltr (UK)	22	AD022	Fan Support
CD085 Polar Freezer St/St - 600Ltr (UK)	23	AD006	Condenser
CD085 Polar Freezer St/St - 600Ltr (UK)	24		Unite Room Grills
CD085 Polar Freezer St/St - 600Ltr (UK)	25	AD015	Evaporator Fixer
CD085 Polar Freezer St/St - 600Ltr (UK)	26	AC614	Sensor

Exploded diagram and spare parts list
R134a



Machine	Explode	Code	Description
CD085 Polar Freezer St/St - 600Ltr (UK)	1	AD037	Up Hinge
CD085 Polar Freezer St/St - 600Ltr (UK)	2	AD027	Hook Of Lock
CD085 Polar Freezer St/St - 600Ltr (UK)	3		Thermostat Support
CD085 Polar Freezer St/St - 600Ltr (UK)	4	AD341	Front Panel
CD085 Polar Freezer St/St - 600Ltr (UK)	5	AD028	Lock
CD085 Polar Freezer St/St - 600Ltr (UK)	6	AD032	Thermostat
CD085 Polar Freezer St/St - 600Ltr (UK)	7	AD026	Hinge Axis
CD085 Polar Freezer St/St - 600Ltr (UK)	8	AB354	Bushing
CD085 Polar Freezer St/St - 600Ltr (UK)	9	AD025	Gasket
CD085 Polar Freezer St/St - 600Ltr (UK)	10		Door
CD085 Polar Freezer St/St - 600Ltr (UK)	12	AD013	Down Hinge
CD085 Polar Freezer St/St - 600Ltr (UK)	13		Evaporator Support
CD085 Polar Freezer St/St - 600Ltr (UK)	14		Evaporator
CD085 Polar Freezer St/St - 600Ltr (UK)	15	AB361	Foot
CD085 Polar Freezer St/St - 600Ltr (UK)	16		Body
CD085 Polar Freezer St/St - 600Ltr (UK)	17		Plug
CD085 Polar Freezer St/St - 600Ltr (UK)	18	AA691	Junction Box
CD085 Polar Freezer St/St - 600Ltr (UK)	19	AA806	Compressor
CD085 Polar Freezer St/St - 600Ltr (UK)	20	AB339	Condenser Fan
CD085 Polar Freezer St/St - 600Ltr (UK)	21	AD036	Unite Board
CD085 Polar Freezer St/St - 600Ltr (UK)	22	AD022	Fan Support
CD085 Polar Freezer St/St - 600Ltr (UK)	23	AD006	Condenser
CD085 Polar Freezer St/St - 600Ltr (UK)	24		Unite Room Grills
CD085 Polar Freezer St/St - 600Ltr (UK)	25	AD015	Evaporator Fixing
CD085 Polar Freezer St/St - 600Ltr (UK)	26	AC614	Sensor