




















Machine	Explode	Code	Description
Rowlett Esprit 6 Slot Toaster	1		Espr-6 Body
Rowlett Esprit 6 Slot Toaster	2		Front Panel/E6
Rowlett Esprit 6 Slot Toaster	3		Inner Assy/E6
Rowlett Esprit 6 Slot Toaster	4		Heat Shield Assy/E6
Rowlett Esprit 6 Slot Toaster	5		Finger Bar/6P
Rowlett Esprit 6 Slot Toaster	6		Back Panel/E6
Rowlett Esprit 6 Slot Toaster	7		Fixed Plate/6P
Rowlett Esprit 6 Slot Toaster	8	AK221	Power Cord
Rowlett Esprit 6 Slot Toaster	9		Power Cord Buckle
Rowlett Esprit 6 Slot Toaster	10		Wire Bushing
Rowlett Esprit 6 Slot Toaster	11	AK222	Fuse Holder
Rowlett Esprit 6 Slot Toaster	12		Fuse
Rowlett Esprit 6 Slot Toaster	13	AK223	Thermostat Cut Out
Rowlett Esprit 6 Slot Toaster	14	AK224	Position Selector
Rowlett Esprit 6 Slot Toaster	15	AK225	Indicator
Rowlett Esprit 6 Slot Toaster	16	AK226	Selector Knob
Rowlett Esprit 6 Slot Toaster	17	AK239	Timer
Rowlett Esprit 6 Slot Toaster	18	AK240	Timer Knob
Rowlett Esprit 6 Slot Toaster	19		Screw/Nut
Rowlett Esprit 6 Slot Toaster	20	AK229	Feet (set 4)
Rowlett Esprit 6 Slot Toaster	21	AK230	Nut
Rowlett Esprit 6 Slot Toaster	22		Spring
Rowlett Esprit 6 Slot Toaster	23		Ejectorbar
Rowlett Esprit 6 Slot Toaster	24		Sphere Knob
Rowlett Esprit 6 Slot Toaster	25		Guard Wire
Rowlett Esprit 6 Slot Toaster	26	AK231	End Element 310W
Rowlett Esprit 6 Slot Toaster	27	AK232	Middle Element 400W
Rowlett Esprit 6 Slot Toaster	28	AK233	Element Link
Rowlett Esprit 6 Slot Toaster	29	AK236	Crumb Tray/E6
Rowlett Esprit 6 Slot Toaster	30		Base Plate/E6
Rowlett Esprit 6 Slot Toaster	31		Casting Chrome for CH185
Rowlett Esprit 6 Slot Toaster	31		Casting White for CH186
Rowlett Esprit 6 Slot Toaster	31		Casting Jet Black for CH187
Rowlett Esprit 6 Slot Toaster	31		Casting Traffic Red for CH188
Rowlett Esprit 6 Slot Toaster	32		Casting Chrome for CH185
Rowlett Esprit 6 Slot Toaster	32		Casting White for CH186
Rowlett Esprit 6 Slot Toaster	32		Casting Jet Black for CH187
Rowlett Esprit 6 Slot Toaster	32		Casting Traffic Red for CH188
Rowlett Esprit 6 Slot Toaster	N/A	AL994	Side & Middle Elements
Rowlett Esprit 6 Slot Toaster	N/A	FS746	Sandwich Cage (Pack of 2)