



CATER-PREP CK0104

ICE CRUSHER

MANUAL

***Please read this manual carefully prior to use
& keep it in a convenient place for future reference.***



CATER KWIK, The Lakeland Catering Centre, Newlands, Ulverston, Cumbria, LA12 7QQ
Tel: 01229 480001 | E-mail: INFO@CATERKWIK.CO.UK

Contents

Thank you for purchasing a Cater-Prep machine. In order to ensure safe operation, you are advised to read to this manual carefully to fully understand the features, operating instructions & maintenance details of this equipment.

	Page
<u>Contents:</u>	2
Using the crusher	3
Notes	4-5



Using the crusher

Ensure the voltage of the machine matches that of the electricity supply.

1. Lift the crusher handle up to the stop point, before plugging the machine in. Turn on the mains power, place the ice into the ice drum.
2. Pull down the handle of the ice crusher, to crush the ice.

Cleaning the machine:

After operation, this should be turned off; then the machine should be wiped down with a dry cloth.

Caution

When using the machine ensure the inlet is not blocked, as this will damage the motor. If this does occur switch off the machine immediately.

Specifications:

Voltage: 220V-240V

Frequency: 50Hz

Device Size: 400x180x310mm

Device Weight: 8KG

Quantity of crushed ice: 65KG/hr

NOTES

NOTES