


CATER-~~PREP~~

Tomato Slicer - Instruction Manual

Model: CK7424 & CK7455



To avoid risk of accidents or damage to the appliance, it is essential to read these instructions before it is installed and used for the first time.


Caterkwik Ltd

The Lakeland Catering Centre
Newlands
Ulverston
Cumbria
LA12 7QQ

01229 480001

info@caterkwik.co.uk





Tomato Slicer - Instruction Manual

Basic Specification

Model	Description	No. Of Blades	Slice Thickness	Dimensions	Weight
CK7424	Tomato Slicer	13	4mm	432 x 202 x 210mm	5.2kg
CK7455	Tomato Slicer	10	5.5mm	432 x 202 x 210mm	5.2kg


Introduction

Thank you for purchasing the Cater-Prep Tomato Slicer. Designed to reduce your prep time, this tomato slicer effortlessly cuts through tomatoes to give you perfect tomato slices.

Please read these instructions carefully, correct maintenance and use of your Cater-Prep product will provide the best possible performance and reliability.

WARNING!

- The blades are **VERY SHARP**. Take care when operating the slicer. Keep your hands away from the blades.
- This appliance is **NOT** intended for use by children, people with reduced physical or mental capabilities or lack of experience unless supervised by a person responsible for their safety.



Tomato Slicer - Instruction Manual

Operation & Maintenance

Operation

1. The Cater-Prep Tomato Slicer will come assembled. Set the unit on a stable and level surface.
2. Carefully place a tomato on the Slide Board like on **Picture 1**.
3. With your hands away from the blades, push the handle towards the blades in one quick motion like **Picture 2**.
4. Remove the sliced tomato.

Cleaning & Maintenance

Note: Proper maintenance plays an important role in maximising the life span and performance of this product.

CAUTION: Be careful of the sharp blades.

- Use warm soapy water to rinse the tomato slicer after each use. Rinse then dry.

