
CW8580 Washing Machine

Exploded Diagram & Parts Key

● Part available — CK Code shown ○ Reference only



NO.	PART	QTY	CK CODE
1	Cabinet Assembly	1	—
2	Side Plate	1	—
3	Door Lock	1	CKP8588
4	Top Cover	1	—
5	Inner Ring	1	CKP2789
6	Dispenser Subassembly	1	CKP2784
7	Plate door sub-assy	1	—
8	Door Handle door sub-assy	1	CKP8682
9	Spring door sub-assy	1	CKP8683
10	Decorative Plate door sub-assy	1	CKP2780
11	Door Plunger door sub-assy	1	CKP8558
12	Spring door sub-assy	1	—
13	Sheet Metal Top Cover door sub-assy	1	—
14	Spring door sub-assy	1	—

NO.	PART	QTY	CK CODE
52	Spring door sub-assy	1	—
15	Lock Pin	2	CKP8557
16	PCB	1	CKP8685
17	Control Panel Subassembly	1	—
18	Cycle Select Knob	1	CWP3814
19	Nozzle Assembly	1	—
20	Rear Cover	1	—
21	Shipping Bracket	2	—
22	Drain Hose Assembly	1	CKP8556
23	Drain Hose Catch	1	—
24	Drain Hose Support	4	—
25	Internal Wire Assembly	1	—
26	Electric Filter Assembly	1	—
27	Adjustable Foot Assembly	4	—

NO.	PART	QTY	CK CODE
28	Service Plate Box	1	—
29	Lint Filter Door	1	—
30	Suspension Spring	4	CKP4245
31	Door Gasket	1	CKP8581
32	Clip Spring	1	CKP8512
33	Rear Tub Assembly	1	—
34	Pipe Assembly	1	—
35	Basket Assembly	1	—
36	Counterweight Assembly	1	—
37	Front Tub	1	—
38	Assembly	2	—
39	Damper	3	CKP9808
40	Brushless DC Motor	1	CKP8584
41	Tub Drain Hose Assembly	1	—

NO.	PART	QTY	CK CODE
42	Lower Counterweight	1	—
43	Permanent Magnet Synchronous Pump	1	CKP1469
44	Heater	1	CKP8585
45	Air Pipe Assembly	1	—
46	Magnetic Cover Switch	1	—
47	Assembly	1	—
48	Belt	1	CKP8587
49	Water Inlet Valve	1	—
50	Water Level Sensor	1	CKP6626
51	Choke	1	—
–	Water Inlet Hose Assembly not shown	1	—
–	Power Cord (European Standard) not shown	1	—

Parts 7–14 and 52 make up the door sub-assembly. Items marked “not shown” are supplied with the unit but not pictured.