

COMMERCIAL DISHWASHER CHECKLIST



What type of dishwasher do you require?



Undercounter - Up to 80 covers

Please see **pages 2-4.**



Passthrough - 80-250 covers

Please turn to **pages 5-8.**



Flight Machines/ Rack Type - 250+ covers

If you require a **rack type** dishwasher, please call **01229 480001** to discuss options and a site survey with our sales team.



COMMERCIAL DISHWASHER CHECKLIST



Under Counter Dishwashers

1. Do you require a waste pump?

Does the machine drain itself when you remove the bung?

No



It is highly likely that you require a waste pump.

Yes



You do not require a waste pump.

Do you press a button to drain the machine?

Yes




It is highly likely that you require a waste pump.

No



You do not require a waste pump.




Will the waste pipe be below the lowest part of the machine?

No



It is highly likely that you require a waste pump.



Yes



You do not require a waste pump.

Have a look through the scenarios below to help you decide whether you need a waste pump for your machine, or whether it will drain off gravity waste.

Note: We highly recommend that dishwasher waste pipes have traps fitted.



Yes—A waste pump is required.

When choosing your dishwasher, look out for the products that say “drain pump” in the name.



No—A waste pump is not required.

When choosing your dishwasher, look out for the products that do not have “drain pump” in their title.



IF YOU ARE UNSURE WHETHER YOU REQUIRE A WASTE PUMP OR NOT, PLEASE CALL OUR

HELPFUL SALES TEAM ON 01229 480001

COMMERCIAL DISHWASHER CHECKLIST



Under Counter Dishwashers

2. Do you require a water softener?

Hard water can cause damage and decrease the life of machines due to build up of lime scale. Take a look at the links below to help you determine whether you require a water softener to prevent this.




Yes—A 12 litre water softener is required. Click [HERE](#) to view our range of water softener

Brine Tank— Brine tanks are a low maintenance addition to standard water softeners, ideal for larger establishments.

Zero Lime CK2575— Click [HERE](#) to watch our video on our zero lime machine

No— I do not require a water softener.



One way to accurately determine the hardness of your water is with test strips. Click [HERE](#) to view them on our site.

This map shows water hardness levels over the whole of the UK. Use it to see whether you are in a **hard water area**.

COMMERCIAL DISHWASHER CHECKLIST



Under Counter Dishwashers

3. What are your electrical requirements?

3kw (Plug & Play) Single Phase - Recommended for use with hot water feed.

3Kw - 7.2Kw (Hard Wired) Single Phase—Suitable for cold **or** hot water feed.

7.2Kw > (Hard Wired) Three Phase—Suitable for cold or hot water feed.

Note: Many machines can be altered to suit different power supplies so if you have an enquiry , please do not hesitate to contact our sales team on **01229 480001**.

4. Will the unit be floor standing or do you require a stand?

My unit will be floor standing, I do not require a stand— If the dishwasher is placed on the floor, we would usually recommend that a waste pump is fitted.

Yes, I require a stand—Click [HERE](#) to see our range of equipment stands .

If you have would like any more information on our under counter dishwashers, please call our sales team on **01229 480001**

COMMERCIAL DISHWASHER CHECKLIST




Spray Arm —

Single Feed

Twin Feed

Bowl Filler Attachment (if using a one way check valve)

Pass Through Dishwashers



GreasePak —

Yes

No

Inlet with Sink —

Single Bowl

Double Bowls

I do not require a sink

600mm wide (fits 1 standard tray)

1200mm wide (fits 2 standard trays)

1800mm wide (fits 3 standard trays)

I do not require one of these