



Instanta
Supreme 3 & 6

WB2 & WB2-6 Supreme - EXPLODED DRAWING KEY (D.19-SP)			
Drawing No	Description	Part No	Price (£)
1	Heating element (3.0kw, 230V)	E280	62.35
2	Normal Operating Probe (Black wire)	PRB8/A	16.25
3	1/4" to 3/8" Brass Adaptor	FV305	3.44
4	Brass probe holder c/w "Overfill" level sensor (orange wire)	PRB4/A	16.25
5	Safety valve (set to blow @ 25p.s.i.)	SV202	69.01
6	Anti-vacuum & air release valve	V600/B	34.08
7	Water syphon pipe	H/TUBE3	18.20
8	Low-level sensing probe (yellow wire)	PRB3/A	16.25
9	Brass Elbow	H/FF113	8.70
10	Triac (used to switch power to heater(s) via a signal from PCB)	XE851 (3Kw) XE854 (6Kw)	19.24 24.44
11	Brass "T" piece	H/FF122	10.44
12	Braided Water and Steam Pipes	H/FF387	32.50
13	Safety "Trip" P.C.B.	FF851	37.39
14	Main P.C.B.	FF850	152.06
15	Steam dispense wand	DA105/A	64.92
16	Upper tap handle assembly	TP801	38.53
17	Draw-off tap body - Steam	TP800/S	75.85
18	Grey plastic tap collar	XEN303/HT	5.69
19	Water dispense arm complete	DA104/A	66.94
20	Water "aerator" spray & adaptor	H/FF102 & H/FF101	12.72
21	Draw-off tap body - Water	TP800	75.85
22	Pressure gauge	PG11	59.65
23	ON/OFF switch	XEN400	11.53
24	Over-ride pressure-switch (purple wires)	EN266N	36.35
25	Mains pressure-switch (orange wires)	EN264N	36.35
26	Brass flare fitting for pressure switch	H/FF132N	6.42
27	Capillary tube(s) to pressure switches	E270B	16.51
28	Lower water inlet pipe (5/16" copper)	Ring Spares	
29	1/2" to 1/4" brass reducer	BV20	8.69
30	Pressure reduction valve	PR5	67.55
31	Solenoid inlet adapter	SA14/IN	9.92
32	Solenoid valve	SOL14	30.16
33	Solenoid outlet adapter	SA14/M	9.92
34	Non-return valve	NR52	25.06
35	1/2" to 1/4" female adapter	B507	6.67
36	Brass Elbow	H/FF113	8.70
37	Upper water inlet pipe (5/16" copper)	Ring Spares	
38	Complete Inlet Assembly	Ring Spares	
Not shown	6-hole tank gasket	B225	13.87
	8-hole tank gasket	H/FF127	13.47
	13-hole tank gasket	H/FF128	14.05