




## DAILY END OF DAY



- Remove the filter basket from the group handle and fit the blind filter.
- Lock the handle into the group head and press the espresso key on the keypad after 10 seconds press the espresso key again to stop the group, repeat this operation 6 times and empty the group handle between operations.

## WEEKLY OR TWICE IF BUSY



- With the blind filter in the group handle add a teaspoon of Group Head Cleaner into the blind filter. (we recommend only using powder before daily service to eliminate any group blockage)
- Secure the group handle into the group head and activate the pump for 20 seconds.
- Stop the pump and repeat 3 times with a 5 second gap.
- Remove the group handle and run water through the group for 10 seconds rinsing the group handle in the process.
- Replace the group handle and operate the pump for 10 seconds, repeat this step 3 times, empty handle between operations.
- Clean around the group head gasket with a small brush and hot water.
- Replace the filter in the group handle, make one coffee and discard, the group is now ready for use.
- Strip down group handle components and soak overnight in tub of hot water with 2 teaspoons of cleaning powder. In the morning rinse with plenty of hot water.
- With a teaspoon of cleaning powder in a jug of hot water pour down the machine waste pipe (located under the drip tray) this will help keep the drain hose clear.

## STEAM ARM CARE

- During the course of the day after using any product on the steam arm wipe down with a clean soft damp cloth (do not use a scouring type pad).
- After use blast a bit of steam through to clear the arm.
- **DO NOT** leave the steam arm standing in any sort of liquid.
- If the nozzle gets blocked clear the 3 holes out with a paper clip.

