

Exploded diagram and spare parts list GG2016 GG217 GG218


For machines with - R290

[Click](#)

For machines with – R134a

[Click](#)

Exploded diagram and spare parts list GG2016 GG217 GG218
R290




Machine	Explode	GG216	GG217	GG218	Description
Polar Patisserie Display	1				Sliding door
Polar Patisserie Display	2				Ventilation grill
Polar Patisserie Display	3	AE840	AE840	AE840	Digital thermostat (old)-Before 5016687-UK

Exploded diagram and spare parts list GG2016 GG217 GG218

Polar Patisserie Display	3	AG620	AG620	AG620	Old Thermostat(R290)-From 5016687-UK to 5023362-UK
Polar Patisserie Display	3	AG908	AG908	AG908	New Thermostat(R290)-From 5024781-UK
Polar Patisserie Display	4	AG951	AG951	AG951	Control Panel-From 5024781-UK
Polar Patisserie Display	5	AG621	AG621	AG621	Main switch
Polar Patisserie Display	6	AG622	AG622	AG622	Temperature Display
Polar Patisserie Display	7	☎	☎	☎	Top shelf
Polar Patisserie Display	8	☎	☎	☎	Top shelf bracket
Polar Patisserie Display	9	AG623	AG624	AG625	Light(LED)
Polar Patisserie Display	10	AE844	AE850	AE854	Light cover
Polar Patisserie Display	11	☎	☎	☎	Middle shelf
Polar Patisserie Display	12	☎	☎	☎	Middle shelf bracket
Polar Patisserie Display	13	☎	☎	☎	Front s/s air grill
Polar Patisserie Display	14	☎	☎	☎	Bottom shelf
Polar Patisserie Display	15	☎	☎	☎	Rear s/s air grill
Polar Patisserie Display	16	AE845	AE845	AE845	Evaporator fan motor
Polar Patisserie Display	17	☎	☎	☎	Evaporator cover
Polar Patisserie Display	18	☎	☎	☎	Evaporator(R290)
Polar Patisserie Display	19	AG626	AG627	AG628	Compressor(R290)
Polar Patisserie Display	20	AE847	AE852	AE855	Top glass
Polar Patisserie Display	21	☎	☎	☎	Front glass
Polar Patisserie Display	22	☎	☎	☎	Side glass
Polar Patisserie Display	23	AG907	AG907	AG907	Power Supply
Polar Patisserie Display	24	☎	☎	☎	Condenser
Polar Patisserie Display	25	AG629	AG629	AG629	Condenser fan motor
Polar Patisserie Display	26	AG673	AG673	AG673	Dry filter
Polar Patisserie Display	27	AG630	AG630	AG630	Electronic expansion valve
Polar Patisserie Display	28				Electronic expansion valve coil

R134a



Exploded diagram and spare parts list GG2016 GG217 GG218

Machine	Explode	GG216	GG217	GG218	Description
Polar Patisserie Display	1				Sliding door
Polar Patisserie Display	2				Ventilation grill
Polar Patisserie Display	3				Control panel
Polar Patisserie Display	4	AE840	AE840	AE840	Digital thermostat
Polar Patisserie Display	5	AE841	AE841	AE841	Switch
Polar Patisserie Display	6	AE596	AE596	AE596	Power Switch
Polar Patisserie Display	7				Automatic expansion valve
Polar Patisserie Display	8				Top shelf
Polar Patisserie Display	9				Top shelf bracket
Polar Patisserie Display	10	AE843	AE849	AE853	Light
Polar Patisserie Display	11	AE844	AE850	AE854	Light cover
Polar Patisserie Display	12				Middle shelf
Polar Patisserie Display	13				Middle shelf bracket
Polar Patisserie Display	14				Front s/s air grill
Polar Patisserie Display	15				Bottom shelf
Polar Patisserie Display	16				Rear s/s air grill
Polar Patisserie Display	17	AE845	AE845	AE845	Evaporator fan motor
Polar Patisserie Display	18				Evaporator cover
Polar Patisserie Display	19				Evaporator
Polar Patisserie Display	20	AE846	AE851	AE851	Compressor(R134a)
Polar Patisserie Display	21	AE847	AE852	AE855	Top glass
Polar Patisserie Display	22				Front glass
Polar Patisserie Display	23				Side glass
Polar Patisserie Display	24				Condenser
Polar Patisserie Display	25	AE848	AE848	AE848	Condenser fan motor
Polar Patisserie Display	26				Dry filter