







Machine	Explode	Code	Description
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	1	AL637	Lid Handle
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	2	AM223	S/S Lid
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	3		Body Handle
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	4		S/S Reservoir
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	5	AF336	Tap
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	N/A	AN830	Plastic Handle for Tap
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	6	AL682	Thermal Cut out
GL347 - Buffalo Manual Fill Water Boiler 20Ltr			Manual-Reset Assembly
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	7		Steel Support Bracket
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	8	AN236	S/S Base
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	9		Bottom Cover
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	10	AC641	Plastic Foot
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	11	AK110	Temperature Dial
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	12	AK818	105C Thermostat
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	13	AL401	Red Control Light
GL347 - Buffalo Manual Fill Water Boiler 20Ltr		AL402	Green Control Light
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	14		Power Cord&Plug
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	15	AN649	Power Cord Clip