




Machine	Explode	Code	Description
HZ897 - Buffalo Induction Stock Pot - 5kW	1	AS876	Ceramic Glass
HZ897 - Buffalo Induction Stock Pot - 5kW	2		Stainless Steel Top Cover
HZ897 - Buffalo Induction Stock Pot - 5kW	3		Stainless Steel Front Cover
HZ897 - Buffalo Induction Stock Pot - 5kW	4		Stainless Steel Housing
HZ897 - Buffalo Induction Stock Pot - 5kW	5		Power Strip
HZ897 - Buffalo Induction Stock Pot - 5kW	6		Connect Cable
HZ897 - Buffalo Induction Stock Pot - 5kW	7	AS877	Mainboard
HZ897 - Buffalo Induction Stock Pot - 5kW	8	AS878	UK Power Cord
HZ897 - Buffalo Induction Stock Pot - 5kW	9		Inside Plastic Housing
HZ897 - Buffalo Induction Stock Pot - 5kW	10	AS879	Fan
HZ897 - Buffalo Induction Stock Pot - 5kW	11	AS880	Filter Board
HZ897 - Buffalo Induction Stock Pot - 5kW	12	AS558	Indicator Light
HZ897 - Buffalo Induction Stock Pot - 5kW	13	AS881	Control PCB
HZ897 - Buffalo Induction Stock Pot - 5kW	14		Control Panel
HZ897 - Buffalo Induction Stock Pot - 5kW	15	AS559	Knob
HZ897 - Buffalo Induction Stock Pot - 5kW	16	AS882	Sensor
HZ897 - Buffalo Induction Stock Pot - 5kW	17	AS883	Heating Coil
HZ897 - Buffalo Induction Stock Pot - 5kW	18	AS884	Air Filter