




Machine	Explode	Code	Description
Buffalo Bakery Convection Oven - 600x400mm trays	1	AW172	Door Seal
Buffalo Bakery Convection Oven - 600x400mm trays	2	AW173	Door Assembly
Buffalo Bakery Convection Oven - 600x400mm trays	3	AW174	Timer
Buffalo Bakery Convection Oven - 600x400mm trays	4	AW175	Timer Knob
Buffalo Bakery Convection Oven - 600x400mm trays	5	AW176	Power/Red Indication Light
Buffalo Bakery Convection Oven - 600x400mm trays	6	AW177	Working/Green Indication Light
Buffalo Bakery Convection Oven - 600x400mm trays	7	AW178	Temperature Knob
Buffalo Bakery Convection Oven - 600x400mm trays	8	AW179	Thermostat
Buffalo Bakery Convection Oven - 600x400mm trays	9	AW180	Manual Humidity Button
Buffalo Bakery Convection Oven - 600x400mm trays	10	AW181	Feet (set 4)
Buffalo Bakery Convection Oven - 600x400mm trays	11	AW182	Door Switch
Buffalo Bakery Convection Oven - 600x400mm trays	12	AW183	Internal Light
Buffalo Bakery Convection Oven - 600x400mm trays	13	AW184	Wire Buckle
Buffalo Bakery Convection Oven - 600x400mm trays	14	AW185	Temperature Limiter
Buffalo Bakery Convection Oven - 600x400mm trays	15	AW186	AC Conductor
Buffalo Bakery Convection Oven - 600x400mm trays	16	AW187	UK Power Cord
Buffalo Bakery Convection Oven - 600x400mm trays	17	AW188	Heating Element
Buffalo Bakery Convection Oven - 600x400mm trays	18	AW189	Fan Motor
Buffalo Bakery Convection Oven - 600x400mm trays	19	AW190	Water Pump
Buffalo Bakery Convection Oven - 600x400mm trays	20	AW191	Rebound Device
Buffalo Bakery Convection Oven - 600x400mm trays	21	AW192	Water Tank
Buffalo Bakery Convection Oven - 600x400mm trays	22	AW193	Shelf