












VOGUE

JF007: Adjustable Dish Caddy

Packed parts

A  × 1	B  × 2	C  × 1
D  × 6	E  × 6	F  × 6
G  × 14	H  Small lock washer × 6	I  Big lock washer × 14


Assembly tool




Manual size A4: back page

Loading guide


Layout for 7" to 9", 5.5" to 7" and 4.5" plates




Layout for 9" to 13" plates




Layout for 9" to 13" plates and 5" plates




Layout for 7" to 9" plates and 4.5" plates



Layout for 7" to 9" plates



Layout for 5.5" to 7" plates



UK	0117 3075655	service@technical-sales.co.uk	Fourth Way, Avonmouth, Bristol, BS11 8TB United Kingdom
Eire	021 4946777	Sales@nisbets.ie	Unit 9003, Blarney Business Park, Blarney Co. Cork, Ireland
NL	040 2628080	service@nisbets.nl	
FR	01 60342880	sav@nisbets.fr	
BE-NL	0800-29129	service@nisbets.be	

BE-FR	0800-29229	service@nisbets.be	
DE	0800 1860806	service@nisbets.de	
ES	901 100 133		
AU	1300 225 960		15 Badgally Road, Campbelltown, 2560, NSW, Australia
NZ	0800 222 700		

vogue-cookware.com 