

# L04 Laundry Eco Bleach

## Active oxygen bleaching agent

Electrolux Professional Ecolabel range contains efficient and environmentally friendly ingredients. Meeting the requirements of ECOLABEL involves complying with extremely strict specifications, rigorous performance criteria, ultimate aerobic and anaerobic biodegradability and 100% recyclable packaging.

This product is part of a multicomponent system.



### Use:

L04 Laundry Eco Bleach is a stain remover for white and colored fabrics, active between 30°C and 70°C. Suitable for soiled and delicate textiles (wool, silk). L04 Laundry Eco Bleach is not dangerous for fabrics and preserves colors.




Contains Hydrogen peroxide, acetic acid and peracetic acid.

### Instructions for use:

- Wash at the minimal recommended temperature.
- Every time and for every kind of laundry, wash with the maximum weight possible.
- Follow the dosage instructions according to the water hardness and to the soiling levels.
- By using this product bearing the European Ecolabel in accordance with dosing recommendations, you help reduce water pollution and energy consumption.
- This product is included in a multi-components system.

### Recommended dosage for 1 kg of laundry

To wash as efficiently as possible and avoid waste, we advise you to get information about water hardness level in your area and to follow the instructions below:

			
Soft water	5 g/kg	10 g/kg	15 g/kg
Medium water	5 g/kg	10 g/kg	15 g/kg
Hard water	8 g/kg	10 g/kg	15 g/kg

### Physical-chemical

Density (20	1.115 g/ml
pH-value (at 1	2.7



**Packaging** 20 L canister

**Code** OW7RBD (PNC 432731141)

### Safety and Transport



GHS03, GHS05, GHS07, GHS09, UN3149