


For machines with R600a refrigerant -


[Click](#)

For machines with R134a refrigerant -

[Click](#)



Machine	Explode	Code	Description
Polar 4 Drawer Counter	1	AB308	Main Switch
Polar 4 Drawer Counter	2	AB363	Thermostat
Polar 4 Drawer Counter	3	AA631	Plastic Cap
Polar 4 Drawer Counter	4	AA694	Filter
Polar 4 Drawer Counter	5		Drawer
Polar 4 Drawer Counter	6	AE829	Guide Left
Polar 4 Drawer Counter	7	AE828	Guide Right
Polar 4 Drawer Counter	8	AC613	Gasket
Polar 4 Drawer Counter	9		Screw
Polar 4 Drawer Counter	10		Washer
Polar 4 Drawer Counter	11	AG178	Bridge
Polar 4 Drawer Counter	12	AB361	Feet
Polar 4 Drawer Counter	13	AA634	Drain Pipe Nut
Polar 4 Drawer Counter	14	AA637	Drain Pipe
Polar 4 Drawer Counter	15	AA638	Drain Pipe Cover
Polar 4 Drawer Counter	16		Body
Polar 4 Drawer Counter	18	AB975	Top Hinge
Polar 4 Drawer Counter	19		Top
Polar 4 Drawer Counter	20		Airflow Duct
Polar 4 Drawer Counter	21	AA639	Sensor Fixed Clip
Polar 4 Drawer Counter	22	AC614	Sensor
Polar 4 Drawer Counter	23		Circle Fan Support
Polar 4 Drawer Counter	24	AB339	Circle Fan
Polar 4 Drawer Counter	25	AA906	Condenser
Polar 4 Drawer Counter	26		Discharge Tube
Polar 4 Drawer Counter	27	AB309	Condenser Fan
Polar 4 Drawer Counter	28	AA658	Basket Guard Grills
Polar 4 Drawer Counter	29	AB984	Water Pan
Polar 4 Drawer Counter	30	AG014	Compressor (R600a)
Polar 4 Drawer Counter	32		Capillary
Polar 4 Drawer Counter	33	AB163	Filter Drier
Polar 4 Drawer Counter	34		Unit Board
Polar 4 Drawer Counter	35		Condenser Cover Board
Polar 4 Drawer Counter	36		Plug
Polar 4 Drawer Counter	37	AA728	Junction Box
Polar 4 Drawer Counter	38	AA795	Front Panel
Polar 4 Drawer Counter	39		Back Support Left
Polar 4 Drawer Counter	40		Front Side Support Left
Polar 4 Drawer Counter	41		Front Side Support Right
Polar 4 Drawer Counter	42		Back Support Right
Polar 4 Drawer Counter	43		Back Middle Support Right
Polar 4 Drawer Counter	44		Back Middle Support Left



Machine	Explode	Code	Description
Polar 4 Drawer Counter	1	AB308	Main Switch
Polar 4 Drawer Counter	2	AB363	Thermostat
Polar 4 Drawer Counter	3	AA631	Plastic Cap
Polar 4 Drawer Counter	4	AA694	Filter
Polar 4 Drawer Counter	5		Drawer
Polar 4 Drawer Counter	6	AE829	Guide Left
Polar 4 Drawer Counter	7	AE828	Guide Right
Polar 4 Drawer Counter	8	AC613	Gasket
Polar 4 Drawer Counter	9		Screw
Polar 4 Drawer Counter	10		Washer
Polar 4 Drawer Counter	11	AG178	Bridge
Polar 4 Drawer Counter	12	AB361	Feet
Polar 4 Drawer Counter	13	AA634	Drain Pipe Nut
Polar 4 Drawer Counter	14	AA637	Drain Pipe
Polar 4 Drawer Counter	15	AA638	Drain Pipe Cover
Polar 4 Drawer Counter	16		Body
Polar 4 Drawer Counter	17		Back Support
Polar 4 Drawer Counter	18	AB975	Top Hinge
Polar 4 Drawer Counter	19		Top
Polar 4 Drawer Counter	20		Airflow Duct
Polar 4 Drawer Counter	21	AA639	Sensor Fixed Clip
Polar 4 Drawer Counter	22	AC614	Sensor
Polar 4 Drawer Counter	23		Circle Fan Support
Polar 4 Drawer Counter	24	AB339	Circle Fan
Polar 4 Drawer Counter	25	AA906	Condenser
Polar 4 Drawer Counter	26	AE831	Discharge Tube
Polar 4 Drawer Counter	27	AB309	Condenser Fan
Polar 4 Drawer Counter	28		Basket Guard Grills
Polar 4 Drawer Counter	29	AD038	Water Pan
Polar 4 Drawer Counter	30	AB865	Compressor
Polar 4 Drawer Counter	32		Capillary
Polar 4 Drawer Counter	33	AB163	Filter Drier
Polar 4 Drawer Counter	34		Unit Board
Polar 4 Drawer Counter	35		Condenser Cover Board
Polar 4 Drawer Counter	36		Plug
Polar 4 Drawer Counter	37	AA728	Junction Box
Polar 4 Drawer Counter	38	AA795	Front Panel
Polar 4 Drawer Counter	39		Back Support
Polar 4 Drawer Counter	40	AB964	Side Support
Polar 4 Drawer Counter	N/A	AB857	Standard Castor
Polar 4 Drawer Counter	N/A	AC099	Braked Castor