

	Denominación	Description	Denomination
B.LAV	LED BOMBA LAVADO	WASH PUMP LED	LED POMPE DE LAVAGE
BOYA INF.	LED BOYA INFERIOR	LOWER FLOAT LED	LED BOUÉE INFÉRIEUR
BOYA SUP.	LED BOYA SUPERIOR	UPPER FLOAT LED	LED BOUÉE SUPÉRIEUR
B.PRES	LED BOMBA PRESION	BOOSTER PUMP LED	LED POMPE DE PRESSION
B.VAC	LED BOMBA VACIADO	DRAIN PUMP LED	LED POMPE DE VIDANGE
C	CONDENSADOR MOTOR	CAPACITOR MOTOR	CONDENSATEUR MOTEUR
C.CALD	LED CONTACTOR CALDERIN	BOILER CONTACTOR LED	LED CONTACTEUR CHAUDIÈRE
C.CUBA	LED CONTACTOR CUBA	TANK CONTACTOR LED	LED CONTACTEUR CUVE
C1	CONTACTOR RESISTENCIA CALDERIN	BOILER SAFETY THERMOSTAT	CONTACTEUR RESISTANCE CHAUDIERE
C2	CONTACTOR RESISTENCIA CUBA	BOILER ELEMENT CONTACTOR	CONTACTEUR RESISTANCE CUVE
C3	CONTACTOR BOMBA LAVADO	TANK ELEMENT CONTACTOR	CONTACTEUR POMPE LAVAGE
D1	REGLETA CONEXION	TERMINAL STRIP	REGLETTE CONNEXION
EVA	LED ELECTROVALVULA	ELECTROVALVE LED	LED ELECTROVALVE
EV1	ELECTROVALVULA AGUA CALIENTE	HOT WATER ELECTROVALVE	ELECTROVALVE EAU CHAUDE
F3	FILTRO SUPRESION INTERFERENCIAS	INTERFERENCE SUPPRESSION FILTER	FILTRE SUPPRESSION INTERFÉRENCES
F4	FUSIBLE	FUSE	FUSIBLE
F5	FUSIBLE ELECTROVALVULA	ELECTROVALVE FUSE	ELECTROVALVE FUSIBLE
I1	INTERRUPTOR GENERAL	MAIN SWITCH	INTERRUPTEUR GENERAL
I3	INTERRUPTOR MAGNETICO PUERTA	DOOR MAGNETIC SWITCH	INTERRUPTEUR MAGNETIQUE PORTE
I8	BOYA NIVEL BAJO DEPOSITO	LOW LEVEL FLOAT	BOUEE NIVEAU BAS CUVE
I9	BOYA NIVEL ALTO DEPOSITO	HIGH LEVEL FLOAT	BOUEE NIVEAU HAUT CUVE
M1	BOMBA LAVADO	WASH PUMP	POMPE DE LAVAGE
M3	BOMBA VACIADO	DRAIN PUMP	POMPE DE VIDANGE
M4	DOSIFICADOR DETERGENTE	DETERGENT DOSER	DOSEUR DE DETERGENT
M5	BOMBA PRESION	BOOSTER PUMP	POMPE DE PRESSION
M8	VENTILADOR EXTRACTOR-CONDENSADOR VAHOS	EXTRACTOR FAN-CONDENSER STEAM	VENTILATEUR D'EXTRACTION-CONDENSEUR DE VAPEUR
NTC1	SONDA TEMPERATURA CALDERIN	BOILER TEMPERATURE PROBE	SONDE TEMPERATURE CHAUDIERE
NTC2	SONDA TEMPERATURA CUBA	TANK TEMPERATURE PROBE	SONDE TEMPERATURE CUVE
NTC3	SONDA TEMPERATURA ACLARADO	RINSING TEMPERATURE PROBE	SONDE TEMPERATURE RINÇAGE
POT1	AJUSTE TEMPERATURA CALDERIN	BOILER TEMPERATURE ADJUSTEMENT	REGLAGE TEMPERATURE CHAUDIÈRE
POT2	AJUSTE TEMPERATURA CUBA	TANK TEMPERATURE ADJUSTEMENT	REGLAGE TEMPERATURE CHAUDIÈRE
PRES.ALTO	LED PRESOSTATO ALTO	HIGH LEVEL PRESSURESTAT LED	LED PRESSOSTAT HAUT
PRES.BAJO	LED PRESOSTATO BAJO	LOW LEVEL PRESSURESTAT LED	LED PRESSOSTAT BAS
P2	PRESOSTATO NIVEL ALTO	HIGH LEVEL PRESSURESTAT	PRESSOSTAT NIVEAU HAUT
RESER	LED SALIDA RESERVA	LED RESERVE IN	LED SORTIE RESERVE
RESERVA	LED ENTRADA RESERVA	LED RESERVE OUT	LED ENTRÉE RESERVE
R1	RESISTENCIA CALDERIN	BOILER ELEMENT	RESISTANCE CHAUDIERE
R2	RESISTENCIA CUBA	TANK ELEMENT	RESISTANCE CUVE
SW1	INTERRUPTOR DESCONEXION RESISTENCIAS	ELEMENT DISCONNECTION SWITCH	INTERRUPTEUR DEBRANCHER RESISTANCE
TEMP CALD	AJUSTE TEMPERATURA CALDERIN	BOILER TEMPERATURE ADJUSTEMENT	REGLAGE TEMPERATURE CHAUDIÈRE
TEMP CUBA	AJUSTE TEMPERATURA CUBA	TANK TEMPERATURE ADJUSTEMENT	REGLAGE TEMPERATURE CHAUDIÈRE
T3	TERMOSTATO SEGURIDAD CALDERIN	BOILER SAFETY THERMOSTAT	THERMOSTAT SECURITE CHAUDIERE
VDR	VARISTOR	VARISTOR	VARISTOR

