

How to install CK8122 Swivel Castors on to Cater-Cook/Cater-Wash Tables

Step 1. Remove the existing feet as shown. As they are pressure fit, they can sometimes require extra to remove. A handy pair of pliers can help you remove them.

Step 2. Assemble the castor mounts as shown. The metal nut can be placed in any orientation.

Step 3. Fit the newly assembled mount into the leg. If it appears too tight, the use of a rubber mallet or pressing the leg on to a hard surface can help fully fit the mount.

Step 4. Screw your castors on to the mounts. They are now fully installed.

