

# FITTING INSTRUCTIONS

KNEE OPERATED WASH  
HAND BASINS

HB300PFB-WRAS

HB300PFB - WRASNSB



## CONTACT

01327 311144

sales@die-pat.co.uk

www.die-pat.co.uk

## BOX CONTENTS

1	Knee operated wash basin
1	Splashback (optional)
1	Water hose
1	Mixer valve
1	Operating valve
1	Swan neck swivel spout
1	Waste kit

**Important:**

Before installation , please read & understand the instructions.

Installation, commissioning & maintenance must be performed by a technician qualified in accordance with legal requirements .

## INSTALLATION

- Attach a right angled elbow to non-concussive valve
- Attach mixer valve to elbow
- Connect the water hose in position on the valve and attach the other end to the swan neck spout
- After installation, turn the adjustment screws until you reach your desired water temperature
- Position on the wall using the keyhole slots, then secure by screw fixing through the two lower holes

## GENERAL

- Ensure the wall structure is suitable to support the product during use
- Die-Pat accept no responsibility for loss or damage caused by poor installation or operator mis-use
- Do not use abrasive or acid based cleaning products
- For general cleaning use soap or mild detergent and water