



INSTRUCTION REF: IN169
ISSUE No. 1
DATE 21.07.09
Page 1 of 8

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

INSTRUCTIONS

MODEL: MWB

SAFETY INSTRUCTIONS

INSTALLATION INSTRUCTIONS

OPERATION INSTRUCTIONS

MAINTENANCE INSTRUCTIONS

WARRANTY INFORMATION

DISPOSAL INFORMATION

Customer Information

MODEL NUMBER: _____
SERIAL NUMBER: _____
PURCHASE DATE: _____
DISTRIBUTOR: _____



INSTRUCTION REF: IN169
ISSUE No. 1
DATE 21.07.09
Page 2 of 8

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

SAFETY INSTRUCTIONS

IMPORTANT, PLEASE READ INSTRUCTIONS FULLY BEFORE USE

Please be aware that surfaces on this machine may get very hot during, and after use.

ALL APPLIANCES OTHER THAN THOSE FITTED WITH A SEALED MOULDED PLUG MUST BE FITTED BY A QUALIFIED ELECTRICIAN, IN ACCORDANCE WITH CURRENT REGULATIONS.

The unit should be installed in compliance with the INSTALLATION INSTRUCTIONS and the NATIONAL REGULATIONS in force at the time. Particular attention should be paid to the Health and Safety at Work Act.

To prevent shocks, all appliances whether gas or electric, must be earthed.

To avoid scratching the highly polished exterior surface of this equipment whilst in transit, the protective film on the exterior surfaces has NOT been removed.

It is IMPORTANT that this protective film is peeled off before the equipment is used.

ENSURE THE APPLIANCE IS ISOLATED FROM THE POWER SUPPLY BEFORE INSTALLING, CLEANING OR MAINTAINING THE APPLIANCE



INSTRUCTION REF: IN169
ISSUE No. 1
DATE 21.07.09
Page 3 of 8

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536


INSTALLATION INSTRUCTIONS

- This unit is supplied with a moulded plug

OPERATION INSTRUCTIONS

Position mobile wash basin in desired location.

Remove soap dish to gain access to water tank. Fill with water to maximum water level tab, as shown in image below



Ensure waste bucket is in position and the waste pipe is placed inside the bucket.

Plug into suitable 13amp protected supply.

Ensure red power light in back of unit below the water tank is lit as shown in image below.

Parry Group Limited, Town End Road, Draycott, Derby, England DE72 3PT
www.parry.co.uk



INSTRUCTION REF: IN169
ISSUE No. 1
DATE 21.07.09
Page 4 of 8

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536



Red Power Light

Drain Tap

Allow 20mins for the water to reach temperature before use.

To fill basin with water use the foot pump at the front of the machine.

Unit is protected from overheating by a control stat. If the tank has an insufficient amount of water in it, a pressure switch will cut electricity supply to the element preventing boiling dry, and damage to the element.

Before moving unit to new location make sure water tank is emptied by tap located on the bottom of the tank as shown in the photo.

Please note that the waste bucket should be emptied regularly.



INSTRUCTION REF: IN169
ISSUE No. 1
DATE 21.07.09
Page 5 of 8

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

MAINTENANCE INSTRUCTIONS

Care and Cleaning

IMPORTANT NOTE

Turn off the mains switch before commencing any of the below.

Proprietary cleaners must be used with care . they are highly corrosive and may cause damage to surfaces and components.

To clean unit wipe down with warm soapy water.

DO NOT USE SCOURING PADS.



INSTRUCTION REF: IN169
ISSUE No. 1
DATE 21.07.09
Page 6 of 8

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

WARRANTY INFORMATION

WARRANTY POLICY

- The manufacturers warranty is only valid in the UK mainland & Northern Ireland, Western Isles, Inner Hebrides and Islands are parts only warranty.
- All service calls will be carried out between the hours of 8.00am . 5.00pm Monday to Friday only.
- We accept no responsibility for delays in replacing or repairing the equipment due to circumstances beyond our control.
- Your warranty can be immediately invalid if the installation of the equipment has not been installed in accordance with the manufactures instruction. (See installation details). Also the miss-use, alteration or unauthorised repairs of the equipment will invalidate the warranty.
- During the warranty period it is at Parrys discretion to repair or replace the equipment.
- Warranty only applies if the equipment has been used in a professional manor following the manufactures instructions and maintenance guide lines.
- The warranty covers defects in the material and components failure only we are not liable for trading loss, loss of perishable items, water damage, loss due to injury or fire damage.

WARRANTY REQUEST

- Please ensure you have referred to the manufacturersqinstruction before placing a warranty call. Or contact our warranty department on 01332 875665 for technical assistance. Please ensure you obtain the model number before calling.
- Please ensure you have read the section not covered under warranty to avoid any unnecessary warranty charges.
- If the problem with the machine can not be resolved please contact the company that supplied you the machine.

(SERVICE CALLS CAN NOT BE PLACED DIRECT WITH PARRY)

Parry Group Limited, Town End Road, Draycott, Derby, England DE72 3PT
www.parry.co.uk



INSTRUCTION REF: IN169
ISSUE No. 1
DATE 21.07.09
Page 7 of 8

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

NOT COVERED UNDER WARRANTY

- Fault due to poor maintenance.
- Resetting of equipment or circuit breakers.
- Abuse of the equipment
- Foil should never be used on racks
- Blockages eg, drains, condensers, pumps etc
- Lime scale related issues
- Installed incorrectly
- Access arranged for service call and engineer refused access or customer not there.
- No faults with the machine.
- Setting up of equipment eg, dishwasher detergents, levelling and setting up of doors on a 6 burner cooker.
- Excessive carbon build up on griddle plates.
- Over use of lava rock on the chargrills recommended use by Parry 2kg only.
- Faulty electrics . eg, customers plug socket, plug, wiring, junction box fault, wrong fuse.
- Any damages caused by the customer.
- Lamps, glass, door gaskets, Perspex, baskets, knobs all perishable items are not covered.

All of the above are not covered under our warranty policy. Any costs incurred because of the above will be forwarded to the parties responsible for placing the call.

Failure to pay any warranty charges will result in the customers warranty been put on hold until the bill has been settled.

Any issues regarding the raised charges should be put in writing to our warranty department for further investigation.

Parry Group Limited, Town End Road, Draycott, Derby, England DE72 3PT
www.parry.co.uk



INSTRUCTION REF: IN169
ISSUE No. 1
DATE 21.07.09
Page 8 of 8

TELEPHONE: SERVICE (44) 01332 875665
FAX: SERVICE (44) 01332 875536

DISPOSAL INFORMATION

Parry Catering recognises our obligations to the EU DIRECTIVE covering the waste disposal of electrical and electronic equipment (WEEE), Parry Catering are committed to this policy in order to help conserve the environment.

At the end of this unit's life you **MUST** dispose of it in an approved manner. You **MUST** not discard the unit or place it in the refuse bin.

You have several options:

- a) Take the unit to an approved WEEE scheme company, there will be one in your area.
- b) Take the unit to an approved waste disposal site; many sites are managed by your local authority.
- c) Contact the unit's manufacturer, importer or their agent the contact details will be on the unit.

There will probably be a charge for this service which will depend on the physical location of the unit and size you will be given a collection price for a curb side collection based on commercial rates prevailing at the time.

It should be noted that the unit to be collected should be suitably packed and sealed to prevent dangerous gases and fluids from escaping. The condition of the unit must also be clean to comply with health and safety regulations.