



Quantum™ HBH950 Series Programs

Blend Set	Blend Cycle	Total Seconds	Description (speed / seconds)
Smoothies	single smoothie	20	low 6 / med 4 / high 10
	double smoothie	25	low 6 / med 4 / high 15
	thick smoothie	30	low 10 / med 5 / high 15
	heavy smoothie	35	low 5 / med 10 / high 20
	hard to blend	45	low 12 / ramp 12 / high 21
Ice Cream Drinks	small shake	15	low 5 / med 10
	single shake	17	low 5 / med-high 12
	double shake	20	med 10 / high 10
	hard shake 1	20	med 10 / high 10
	hard shake 2	30	med 3 / med-high 7 / high 20
Coffee Drinks	small coffee	13	med-high 7 / high 6
	medium coffee	15	med-high 8 / high 7
	large coffee	20	low 5 / med 5 / high 10
	double coffee	25	low 6 / med 6 / high 13
	thick coffee	30	med 10 / med-low 10 / high 10
Bar Drinks	bar blend 1	12	med 5 / high 7
	bar blend 2	20	med 10 / high 10
	bar blend 3	25	low 4 / med 10 / high 12
	bar blend 4	25	med-high 10 / high 15
	bar blend 5	35	med 10 / low 10 / high 15
Hard to Blend Smoothie	hard to blend 1	25	low 5 / med 5 / high 15
	hard to blend 2	35	low 10 / med 5 / high 20
	hard to blend 3	30	pulse / low 4 / med 10 / high 12
	hard to blend 4	40	pulse / med 15 / high 17
	smoothie bowl	45	high 10 / low 15 / high 10 / low 10
Multipurpose	juice blend 1	15	low 8 / med-high 8
	juice blend 2	30	low 15 / med-low 15
	multipurpose 1	10	low 10
	multipurpose 2	10	high 10
	multipurpose 3	30	low 30
Custom	button 1		Use this option to assign blend cycles from the programs above or blend cycles from a custom program.
	button 2		
	button 3		
	button 4		
	button 5		

Please refer to your operating manual for additional instructions.