



INSTRUCTION MANUAL

Dear Sir or Madam,

A **BIG THANK YOU** from all at Cater-Kwik and congratulations on purchasing your Cater-Cool bottle cooler.

We aim to bring you the best products at industry leading prices.

We expect that you will receive many years trouble free service from your cooler. However, if you have any questions or suggestions on how we might improve any aspect of our Cater-Cool products or service then we would love to hear from you. Please do not hesitate to call or email.

Yours sincerely from all the team at Caterkwik.

01229 480001

info@caterkwik.co.uk



BACK BAR BOTTLE COOLER

Contents

- HOW TO USE..... 2 – 3
- SAFETY PRECAUTIONS..... 4 - 6
- CLEANING..... 7
- IN CASE OF THE FOLLOWING..... 7
- BEFORE REQUESTING SERVICE..... 8
- REQUIRED INFORMATION..... 8



HOW TO USE

BEFORE USE

1. Remove shipping package, tape, etc. Also leave the doors open for ventilation.
2. The unit is cleaned before shipment. However, clean the compartment interior once after delivery.
3. Please insert the power supply plug into the wall outlet, single-phase to cat voltage.
4. Allow the unit to operate for about 1 hour to cool the compartment before placing items in the cooler.

WAIT 5 MINUTES OR MORE BEFORE RE-STARTING

Restarting the unit immediately after it has been turned off may cause fuses to blow and activate the circuit-breaker, the compressor may be overloaded, and/or damage may occur.

TEMPERATURE ADJUSTMENT

The thermostat is pre-set at the factory. To adjust it, turn right for temperature inside the cooler to go down. To raise the temperature, turn it left. Excessive refrigeration will increase electricity consumption unnecessarily.

DRAIN TRAY

Defrosting is performed automatically and drain water is collected in the drain tray.

Water in the drain tray is evaporated automatically. It is recommended that you clean out your drain tray at least once a day.

EFFICIENT USE

Please follow the below instruction, you could save energy.

To prevent cold air from escaping, open and close the door quickly and keep the door opened for as short a time as possible.

Please install the unit in the place which is well-ventilated.

SHELF HEIGHT ADJUSTMENT

The shelf height can be adjusted.

Arrange the shelves in accordance with the dimension of the items to be placed inside the cooler.

HOW TO USE

PLACING ITEMS IN THE BOTTLE COOLER

This bottle cooler employs a forced circulation of cold air system. If circulation of cold air is obstructed, the items will not be adequately refrigerated. Pay attention to the following points:

- Do not let items obstruct the cold air inlet and suction outlet.
- Place items so that they do not protrude from the shelves. The gap between the shelves and the door is used for circulation of cold air.
- Place items evenly on all shelves.
- Please do not display goods on the bottom. Please try to keep them on the shelves.

SETTING THE TEMPERATURE

Operation

Control Panel

For full specification and detailed instructions, please consult the included Dixell manual.

The control panel is located below the doors on the front of the appliance.

Turn On

1. Connect the bottle cooler to a mains power supply.
2. Turn the power switch on.
3. Set the temperature to the desired setting (see below).
4. Close the door of bottle cooler.
5. Turn the light switch on [I] or off [O] as required.

Set the Operating Temperature

1. Press the {set} button. The display will flash.
2. Press the {up arrow} or {down arrow} to display the required temperature.
3. Press the {set} button to store the temperature.

Manual Defrost

The bottle Cooler features an automatic defrost. However, should the appliance require an additional defrost period press and hold the {defrost} button for 6 seconds.

Automatic defrost cycles are every 6 hours and last 20 minutes (factory defaults).

To stop the defrost press and hold the 'defrost' button for 6 seconds.

SAFETY PRECAUTIONS














- To ensure proper use, please thoroughly study these SAFETY PRECAUTIONS before operating the unit.
- The purpose of the safety precautions in this manual is to ensure safe and correct use of the unit to minimize risks that could cause serious damage to either the machine or persons operating it. The safety precautions are divided into warnings and cautions.
- Improper handling of the unit could lead to death or serious injuries, these are listed under the 'WARNING' tab. However, the cases listed 'CAUTION' heading could also lead to serious injuries. To ensure your safety, adhere strictly to both types of safety precautions.
- After reading the instruction manual, store it in a safe and easily accessed place where you can easily go back to it if needed.

PRECAUTIONS FOR INSTALLATION

WARNING

Installation should be performed only by the dealer or a qualified expert, attempting to install the unit yourself could result in water leakage, refrigerant leakage, electrical shock, or a fire.

PRECAUTIONS FOR USE

 WARNING	
 DONT TAMPER <p>All repairs, disassembly and modifications should be performed only by qualified technicians. Attempting to perform this yourself, could result in a fire, malfunction or an injury.</p> 	 ELECTRICAL SHOCK HAZARDS <p>Never splash water directly onto the product or wash with water as a short circuit and electrical leakage could result.</p> 
 DANGER OF EXPLOSION <p>Never put flammable or volatile substances into the unit as explosions or fires could result.</p> 	 PROHIBITED <p>Do not damage, modify, excessively bend, strain, twist or bundle up the power cord. Also, placing heavy objects on the power cord or squeezing it into a tight space could result in damage to the cord, which may lead to an electrical shock or a fire.</p> 
 PROHIBITED <p>Use a dedicated wall outlet. Do not use extensions cords or convenience receptacles as this could result in overheating, which could lead to fires or an electrical shock.</p> 	 FLAMMABLE <p>Never use flammable spray cans or leave flammable substances near the unit. Sparks from electrical switches could result in the flammable substance catching fire or exploding.</p> 

SAFETY PRECAUTIONS

⚠ WARNING



The cooler is intended for storage and display of beer and beverages for sale. Do not use for other purposes than the intended as this could adversely affect items placed in the unit.



Never attempt to insert fingers, sticks, etc. into the cold air suction outlet. A circulation fan is rotating at high speed inside the outlet. Injury, electrical shock and improper operation could result.



PROHIBITED

For indoor use only. Using the unit in a location exposed to rain could result in electrical leakage and electrical shock.




PROHIBITED

Never place heavy objects or items containing water on top of the unit. Objects could fall down and cause injury and spilled water could deteriorate the insulation of electrical components.




Install the unit in a location where the floor is sturdy enough to support the load of the unit, if the floor is not sturdy enough or installation is incorrectly performed, the unit could tip over and falling shelves and products could cause personal injury.



CAUTION AGAINST EXPLOSION

If you find gas leakage, please don't touch the cooler, close all gas valves and open the door for ventilation. Gas leakage could cause an explosion or start a fire.



Store the unit in a location where it is not exposed to rain. Using a unit that has been exposed to rain could result in electrical leakage and electrical shock.



Place the unit away from hot air sources, the cooling performance is reduced if the unit is placed near heat sources such as stoves, or if it is exposed to direct sunlight.



Leave disassembly and disposal of the unit to qualified experts.




Should the unit need temporary storage, make sure not to store the unit in a location where children play and take precautions so that the door cannot be completely closed. This will minimize the risk that a child becomes trapped inside the compartment.


SAFETY PRECAUTIONS

⚠ WARNING

Please make sure there is more than 10cm between the wall and the cooler. If there is no space, the cooling capacity can drop.




If installation in a damp location is unavoidable, also install an electrical leakage circuit breaker. If there is no electrical leakage breaker, this may result in electric shock.




Never hang from the door or climb onto the unit. The unit could tip over and fall and cause the glass to smash or injure someone.



Disconnect the power cord plug from the wall outlet before moving the unit and make sure that the power cord is not damaged during transport. A damaged power cord could result in electrical shock and/or a fire.



Grasp the handle when closing the door. Holding at other positions could result in you trapping your fingers.




Do not apply excessive force to the glass surfaces as the glass could break/smash and cause injury to person/persons.



When disconnecting the power cord plug from the wall outlet, hold at the plug main body, close to the outlet. Pulling on the cord could cause the wire to break, possibly resulting in overheating and a fire.



Make sure that the unit does not tip over or fall when it is moved. A falling unit could cause serious injury.



Do not throw items onto the shelves and do not place items totalling more than 30Kg on each shelf. The shelf could fall, causing injury or break the shelf itself.



Be sure to attach and secure shelves correctly. An improperly attached shelf could fall down and cause injury or break the shelf.





WARNING: Do not splash water directly onto the cooler and do not wash the appliance with water. Short – circuit and electrical shock could result.

- Clean the cooler regularly to keep it clean at all times.
- Never use polishing powder, soap powder, benzene, oil or hot water as these will damage the painting and plastic components.

AFTER CLEANING

To ensure the safety, perform the following checks after cleaning the appliance.

- Is the power cord firmly inserted into a dedicated wall outlet? Confirm that the plug is not abnormally hot.
- Check the power cord for cracks and damage. Should the slightest irregularity be observed, contact the dealer from whom you purchased this unit or our customer service team on 01229 480001.

IN CASE OF THE FOLLOWING

POWER FAILURE

Keep opening and closing the door to a minimum.

Avoid placing new items in the cooler as this will raise the temperature inside the compartment.

WHEN NOT USED FOR A LONG PERIOD

Remove all items from the compartment and disconnect the power cord plug from the wall outlet.

Clean the compartment interior and wipe away all water.

To prevent mould formation and bad smell, leave the door open to dry the compartment completely.

TRANSPORTATION

Disconnect the power cord plug from the wall outlet.

When moving the cooler, make sure that the feet do not damage the power cord.

Do not let the feet hit against floor steps, thresholds, etc.

TEMPORARY STORAGE

Affix a piece of wood, etc. between the door and the main unit to prevent complete closing of the door.

Make sure not to store the unused cooler at a location where children play. Should a child enter the compartment and the door is closed, the child may not be able to open the door from the inside.

BEFORE REQUESTING SERVICE

No refrigeration at all	<ul style="list-style-type: none">● Is the power supply interrupted?● Is the power cord plug disconnected from the wall outlet?● Are the shop's power fuses blown and/or the circuit breaker activated?
Inadequate refrigeration	<ul style="list-style-type: none">● Is the temperature setting appropriate?● Are items obstructing the cold air inlet and suction outlet?● Are stored items packed too tight?● Is the door open or is it opened and closed frequently?● Is the condenser clogged?
Excessive noise	<ul style="list-style-type: none">● Are all the feet in firm contact with the floor?● Is the rear panel of the cooler contacting the wall or other objects?● Is anything in contact with the cooler? E.g. boxes, mops, brushes etc.
Condensation on cooler exterior	<ul style="list-style-type: none">● You may find that on hot and humid days there may be times where a lot of condensation will condense on the exterior and door of the cooler, this is completely normal, clean away the condensation with a cloth.

In the case that you need assistance, please contact our service team on 01229 480001, or E-mail your problem to info@caterkwik.co.uk

REQUIRED INFORMATION

1. Nature of malfunction (as accurately as possible).
2. Product number/serial number (inscribed on the badge).
3. Your name, address & contact details.
4. Year and date of purchase.