

CATER-COOK

Electric Soup Kettle - 10 Litre - Instruction Manual

Model: CK8976



To avoid risk of accidents or damage to the appliance, it is essential to read these instructions before it is installed and used for the first time.




Caterkwik Ltd

The Lakeland Catering Centre
Newlands
Ulverston
Cumbria
LA12 7QQ

01229 480001

info@caterkwik.co.uk





Introduction

Please read these instructions carefully before operating, and keep in a safe place for future reference.

 **CAUTION!** Surfaces of the soup kettle will be hot when it is in use.

Guidelines for use.

- The soup kettle must be placed on a level surface.
- Do not leave the kettle unattended while it is in use.
- Never immerse the kettle in water.
- Do not operate the soup kettle while it is empty.
- Do not overfill the kettle with water.
- Never move or carry the kettle when it is powered on or if it is full of liquid.
- Do not attempt to repair or replace the power cord.
- Take extra care not to touch any hot surfaces.
- Do not allow the power cord to come into contact with any hot surfaces.

Model	CK8976
Capacity	10 Litres
Weight	4.5kg
Dimensions	W350 x D350 x H380mm
Power	220V 50Hz. 400 Watts

Electric Soup Kettle - 10 Litre - Instruction Manual

Operation & Maintenance



 Before using the kettle, ensure it is placed on a solid, level surface.


1. Open the lid and pour 600ml of water into the internal water tank.
2. Take care not to overfill with water. Do not exceed the MAX water level line.
3. Turn the soup kettle by rotating the temperature control.
4. The power indicator will illuminate, showing the soup kettle as on.
5. To power the soup kettle off, rotate the dial counter-clockwise to the OFF position.

NOTE.


The soup kettle is not designed to cool soups or sauces, nor is it designed to defrost frozen products.

Cleaning and Maintenance.

1. Spilled food should be removed immediately from all exterior surfaces.
2. Be sure to clean the soup kettle after every use.
3. To remove dirt or marks from the soup kettle, it is best to wipe with a soft, damp cloth.
4. Do not clean the soup kettle with a high pressure water jet.



Assembly



1. Start with the main body of the kettle, set it down on a level surface.
2. Attach the top part to the main body.
3. Attach the lid at the mounting point indicated.
4. Insert the stainless steel soup container.
5. The soup kettle is now ready to use.