

CW8518 - Equine Washing Machine User Guide

Wash Cycles

Daily Items: For daily items such as boots, bandages, saddle clothes etc. You can use the 31 minute quick wash. This can help to keep those items fresh and remove sweat from daily exercise wear.

For Rugs: For rugs and large bulky items Cater-Wash recommend the 'Heavy/Bulky' or 'Cotton' wash. Select soil level 'Extra Heavy' and the spin speed 'high'. Please check the rug label for temperature setting. You can use the water plus and add steam features for those really dirty rugs!

Re-Proofing: Wash the rug first so it is clean with the wash above. When the cycle has finished, you can add the re proofer in the detergent drawer and then put the machine on Quick Wash.

Make sure all velcro, buckles and surcingles are fastened to prevent snagging & ensure the rug does not get twisted in the drum. When loading the machine take care not trap anything between the door and the door seal..

Maintenance

To ensure your Cater-Wash machine stays odor free and like new you should use the 'Tub Clean' cycle weekly or straight after you have washed a really dirty load!. You can also add a cupful of household bleach for extra cleaning power. - **Do NOT put anything in the washing machine on a tub clean cycle.**

Filter - The filter should be emptied weekly to get rid of any hair or debris in the filter.

Descale - Depending on your water quality, we recommend you descale the machine every 2 months.

